




INTERPHONE VIDÉO CONNECTÉ

## GUIDE D'INSTALLATION ET DE DÉMARRAGE



### 1 TÉLÉCHARGEZ l'application

L'application est disponible sur l'App Store et Google Play (recherchez « Fenotek »).




Appuyez sur COMMENCER AVEC Hi) pour créer votre compte et paramétrer la connexion sans fil. Lorsque l'écran APPAIRAGE BLUETOOTH s'affiche, passez à l'étape 2.


### 2 RELIEZ l'appareil au réseau sans fil

Retirez le bouchon en caoutchouc situé à l'arrière de l'appareil.

Alimentez l'appareil à l'aide du câble USB fourni, branché sur un chargeur de smartphone :



L'appareil s'allume et s'initialise. Lorsque son écran affiche « No connection », appuyez sur le bouton :



Revenez sur l'écran APPAIRAGE BLUETOOTH de votre smartphone et appuyez sur SCANNER.

L'appareil clignote en orange pendant la phase d'appairage, puis s'allume en vert fixe.

Terminez le paramétrage de l'application (nom des boutons, mot de passe) en suivant les instructions, puis appuyez sur CONTINUER ET INSTALLER Hi). L'appareil est maintenant connecté et peut fonctionner avec votre smartphone. Vous pouvez débrancher le câble USB et passer à l'étape 3.


En cas d'anomalie, vérifiez que les informations sur l'écran CONNEXION de votre smartphone sont correctes et recommencez.

### 3 INSTALLEZ l'appareil sur le mur


Coupez le courant avant d'intervenir sur l'installation électrique.

En cas de doute sur l'une de ces instructions, faites appel à un professionnel.


Positionnez le gabarit à l'emplacement prévu de l'appareil (hauteur mini conseillée : 1 m 40) et tracez les 4 trous de fixation. Vérifiez l'aplomb à l'aide d'un niveau à bulle.




Percez les 4 trous de fixation avec un foret de diamètre 6 mm, puis insérez les chevilles :



À l'aide d'un tournevis, percez le bouchon en caoutchouc, et passez les fils à travers :



Raccordez l'appareil selon le schéma suivant :




\* Exemples d'utilisation (matériels non fournis)

Les fils peuvent être branchés dans n'importe quel sens (la polarité est gérée par l'appareil).

Pour connecter un fil : 1. Enfoncez le poussoir orange. 2. Insérez le fil. 3. Relâchez le poussoir.

Une fois les connexions réalisées, remettez en place le bouchon caoutchouc et rangez les excédents de fils pour qu'ils ne gênent pas le montage sur le mur.


Fixez l'appareil sur le mur à l'aide des vis et de la clé Torx Security fournis :



La clé Torx Security est peu commune, conservez-la précieusement.

Rétablissez le courant. L'appareil s'allume en bleu, il est prêt à fonctionner !

Vos visiteurs n'ont plus qu'à appuyer sur ce bouton pour vous appeler :



Vous pouvez modifier l'aspect de l'appareil (couleur des lumières, textes à l'écran, etc.) ou rajouter des utilisateurs en vous rendant dans la rubrique CONFIGURATION de l'application sur votre smartphone :



Un doute, une question ? Rendez-vous sur [fenotek.com](http://fenotek.com)

### Caractéristiques techniques

- Alimentation de l'appareil : 12-24 V DC/AC, min 1 A
- Courant maxi dans les relais : 30 V / 0,6 A
- Température de fonctionnement : -20 °C à +50 °C
- Classe d'étanchéité : IP54
- Intensité minimale de l'alimentation USB pour l'appairage initial : 2 A
- Angle de vision : 130°

### Contenu de la boîte

- Un appareil Hi)
- Un gabarit de perçage en carton
- Un câble micro USB vers USB Type A
- Une clé et 4 vis Torx Security
- 4 chevilles pour matériau plein
- Ce guide d'installation
- Les conditions d'utilisation

### Signification des pictogrammes



Ne jetez pas le produit avec les ordures ménagères. Veillez à le déposer dans un point de collecte ou dans un centre agréé afin de garantir le recyclage.



Lisez attentivement ce guide avant d'installer l'appareil.

App Store est une marque d'Apple Inc. Google Play est une marque de Google Inc. Torx est une marque de Textron, Inc. Fenotek, Hi) et leurs logos respectifs sont des marques déposées par FENOTEK SAS.


FENOTEK SAS  
15 Quai de Rive Neuve  
13007 MARSEILLE  
[www.fenotek.com](http://www.fenotek.com)





SMART VIDEO DOORBELL

## INSTALLATION AND START-UP GUIDE



### 1 DOWNLOAD the app

The app is available from the App Store and Google Play (search for "Fenotek").




Tap START WITH Hi) to create your account and set up the wireless connection. When the BLUETOOTH PAIRING screen appears, go to step 2.


### 2 CONNECT the device to the wireless network

Remove the rubber cap from the back of the device.

Connect the device to a smartphone charger using the USB cable supplied:



The device turns on and initialises. When the screen displays "No connection", press the button:



Go back to the BLUETOOTH PAIRING screen on your smartphone and tap SCAN.

The device flashes orange during the pairing phase, and then the light turns green.

Follow the instructions to finish setting up the app (button names, password) before tapping CONTINUE AND INSTALL Hi). The device is now connected and can communicate with your smartphone. You can unplug the USB cable and continue to step 3.


If there are any problems, check that the information on your smartphone's CONNECTION screen is correct and start again.

### 3 INSTALL the device on the wall


Turn off the electricity before working on the electrical installation.

If you have any doubts about these instructions, contact a professional electrician.


Place the template where the device is to be fitted (recommended minimum height: 1.40 metres) and mark the four fixing holes. Check for straightness using a spirit level.




Drill the four fixing holes with a 6 mm drill bit and insert the wall anchors:



Using a screwdriver, pierce the rubber cap and feed the wires through:



Connect the device according to this diagram:




\* Examples of use (equipment not supplied)

The wires can be connected in either direction (the device handles the polarity).

To connect a wire: 1. Push in the orange button. 2. Insert the wire. 3. Release the button.

Once the connections have been made, replace the rubber cap and tidy away any excess wire so that it does not obstruct the device's contact with the wall.


Attach the device to the wall using the screws and the Torx Security screwdriver supplied:



The Torx Security screwdriver is uncommon, so keep it somewhere safe.

Turn the electricity back on. The device lights up in blue and is ready to use!

Now all your visitors have to do is press this button to call you:



You can change the appearance of the device (light colour, on-screen text etc.) or add users by going to the SETTINGS section of the smartphone app:



If you have any doubts or questions, visit [fenotek.com](http://fenotek.com)

#### Technical characteristics

- Power supply: 12-24 V DC/AC, min 1 A
- Max. relay current: 30 V/0.6 A
- Operating temperature: -20 °C to 50 °C.
- Protection rating: IP54
- Minimum USB current supply for initial pairing: 2 A
- Viewing angle: 130°

#### Box contents

- Hi) device
- Cardboard drilling template
- Micro-USB to USB type A cable
- Torx Security screwdriver and 4 screws
- 4 solid wall anchors
- This installation guide
- Terms of use

#### Meanings of symbols

- Do not dispose of the product with household waste. Take it to a waste collection point or approved centre to ensure it is recycled.
- Read this guide carefully before installing the device.

App Store is a trademark of Apple Inc. Google Play is a trademark of Google Inc. Torx is a trademark of Textron Inc. Fenotek, Hi) and their respective logos are registered trademarks of FENOTEK SAS.

FENOTEK SAS  
15 Quai de Rive Neuve  
13007 MARSEILLE  
France  
[www.fenotek.com](http://www.fenotek.com)

